

#### **WALLMOUNT IP SPEAKER**

## **WWC6-IP**

The WWC6-IP is a 20 watts wallmount IP loudspeaker for voice, paging, intercom, music streaming, audio routing, pre-recorded and scheduled announcement, VoIP communication or as the SIP endpoint where network-wide communication is desired and high-output loudspeakers are required to overcome high ambient noise and/or large spaces.

The WWC6-IP incorporates 3 control inputs for level control and source selection (using the RAC 5/8 controllers), 1 contact output for triggering events. To configure, control, monitor the IP speakers in real-time, this can be easily done through your favorite web browser interface, making the management even the most complex environments simpler than ever.



Certifications	EN 55032, EN 55035,
	EN 61000-3-2, EN 61000-3-3
• Electrical	
Rated power, Watts	20
Effective Frequency Range, Hz (BSEN60268-5)	180-18,500
S.P.L. @ 1 m, 1 Watt, dB, Octave, 100 Hz-10 kHz	82
S.P.L. @ 1 m, Full power, dB, Octave, 100 Hz-10 kHz	90
Dispersion at 1k/2k Hz, Degrees	152/98 Horizontal 128/113 Vertical
Power supply	PoE+ 24 VDC power transformer (18-24 VDC), minimum power supply: 2 A
<b>■</b> Environmental	
IP-rating	21
Min/Max amb temp	-10°C to 55°C
Relative humidity	≤95%
● Mechanical	
Dimensions, Front & Depth, mm	255 x 196 x 82
Net weight, kg	2.33
Colour (Unless Specified)	White, RAL9016
Material	Wooden, White PVC Finish, Steel
Mounting	Wall Mounting
Features	
Configured, controlled, managed and monitored via web	browser
3 control inputs for level control and source selection usin	g the RAC 5/8 controller
1 relay contact output	
Network audio codec: G.711, G.722, WAV, MP3	
3rd party control with TERRACOM system	
Support VoIP call via SIP protocol	




### ATEÏS Europe B.V.


Celsiusstraat 1, 2652 XN Lansingerland, Netherlands Phone +31 (0)10 208 86 90, www.ateis-europe.com, info@ateis-europe.com






# INSTALLATION GUIDE WWC6-IP







- 1) On selecting the chosen position for the loudspeaker (it can be mounted vertically or horizontally) use a spirit level to ensure that it is level. Offer the speaker to the wall or ceiling and mark through the mounting holes, as shown on the drawing to the top, the position required for drilling. Drill 3 holes according to the dimension on the draw.
- 2) Connect cables to the speaker.
- 3) Align the holes on the wooden frame to the holes on the plastic blocks.
- 4) Lock the wooden frame and plastic block together with the screws in the speaker enclosure, and using the plastic caps to cover the screws.


### **SPEAKER CONNECTIONS**



- 1.24 VDC power input
- 2. RJ45 connector Ethernet
- 3. Speaker connection 1 channel 20 W




- 1.3 logic control inputs
- 2.1 contact output
- 3. USB interface (function reserved)





- 1. LED strobe connector (+ -)
- 2. Clock module interface
- **3.** Power LED (+ -)
- 4. Status LED (+ -)

### **FUNCTION BLOCK**





回郑恒

Disclaimer: We reserve the right of changes and errors.



### ATEÏS Europe B.V.

Celsiusstraat 1, 2652 XN Lansingerland, Netherlands Phone +31 (0)10 208 86 90, www.ateis-europe.com, info@ateis-europe.com